



# How to use Thomaston Public Library's Mobile WiFi Hotspot

to wirelessly connect your mobile device / laptop / computer to the internet.

## 1 - Make sure the Hotspot is fully charged.


Plug the AC adapter that came with the Hotspot device into the charging port as shown here, then plug the adapter into an electrical outlet.

The **power button** glows **red** when charging and turns **green** when fully charged.



*(Fully charging a battery may take up to three hours.)*

After charging, unplug the AC adapter from the outlet and unplug the adapter from the Hotspot.



## 2 - Turn on the Hotspot.

Press and **hold** the **power button** until the device displays "Welcome." It will activate automatically but it may take a few minutes for the Hotspot to connect to the Sprint mobile network. The **indicator light** will flash **blue** when the Hotspot is connected to the network.

## 3 - Connect!






On your computer or WiFi enabled device, go to the connection settings and select **SprintWiFi TPL**.

When prompted, enter the password: **Thomaston** You are now connected to the internet!

## 4 - Turn off the Hotspot.

Press and **hold** the **power button** until the device displays "Goodbye." The Hotspot will power off.

To display the icons at right, tap the power button when the Hotspot is powered on.

	Mobile networks connected
	The number of connected WiFi devices
	Battery full
	Battery low
	No battery. Battery icon blinking (charging required)

**Return this Hotspot and Micro-USB Power Adapter to the Thomaston Public Library**  
**For assistance, please call the library at 860-283-4339**